

## Software Update for SRT 5300, SRT 5301(E), SRT 5302 and SRT5303

The following manual describes the procedure for a software update at your receiver via your PC and portable USB device.

### **Hardware Requirements:**

- Windows PC or other operating system with USB or USB 2.0 port. Other systems might require different procedures.
- External USB device

Note: Please check/ensure that power consumption of your USB device is not higher than 5 V/500mA respectively 800 mA. In case of higher power consumption, please use a corresponding power adapter before connecting to your receiver, otherwise your receiver could get damaged.

### **Procedure at PC:**

1. Save the zipped file in a folder of your choice. Unpack the file to this folder (right mouse click: "Unpack here..." or double click -> select "Unpack to", then choose corresponding folder to save the file).
2. Then connect your USB device to an according slot of your PC. Usually your PC shows a message that a new hardware is found/connected (removable disk).
3. Extract the .bin file from the downloaded package to the root directory of the connected USB device.
4. Remove the USB device from your PC by pressing the right mouse button at task bar to "Safely remove hardware" in order to avoid any problems.

### **Procedure at Receiver:**

Switch ON your receiver and connect the USB device with the stored software to the connector at the receiver. After the USB device has been successfully detected, you can perform the software update according to the following steps.

1. Press **MENU** button to enter Main Menu. Select "Tools" with the **▲ ▼** buttons and press **OK** to enter.
2. After entering "Tools" menu, select "Software Upgrade" and press **OK** button. The Software Upgrade menu is shown.
3. Press **▲ ▼** buttons to select "Upgrade by Storage" item and press **OK** button. You are asked to input the password.
4. Enter the correct password (the default password is 0000). The Software Upgrade submenu will be opened.
5. Then select the correct software file and press **OK** to start. A message will be displayed to confirm update process. Select "Yes" to confirm or "No" to cancel.
6. After successfully downloading of the software, press "EXIT" button to exit.

**After the update the receiver restarts automatically! During this process NEVER disconnect the receiver from the main or switch power OFF! This can damage your receiver and warranty will void!**